



6400 E. Industrial Lane • Leavenworth, IN 47137

Phone: 800-752-1700 • Fax 215-781-2618

www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – FFV

Part Number	Description
16512172	ACTUATOR, HAZARD LAMP RED LENS (FFV/ 97 UTILMSTR)
F2DZ3E723A	ACTUATOR, IGNITION SWITCH (98 WSTAR/ FFV)
F77Z9G512AA	ADAPTER, FUEL INJECTOR INLET (FFV)
F77Z6881AA	ADAPTER, OIL FILTER BEFORE 7/24/00 (FFV)
F5TZ2C220B	ADAPTER, PARK BRAKE LS ASSM (FFV)
F5TZ2C220A	ADAPTER, PARK BRAKE RS ASSM (FFV)
XL3	ADDITIVE, REAR AXLE
E3TZ2K389A	ADJUSTER, PARK BRAKE CABLE (FFV)
4G7Z10346AA RM1	ALTERNATOR ASY. (FFV 00-01) REMAN
F6PZ10346AE RM1	ALTERNATOR, (98 WSTAR/LATE FFV) REMAN
4G7Z10346AA RM	ALTERNATOR, (FFV 00 - 01) NEW
F6PZ10346AE	ALTERNATOR, LATE (FFV) NEW 98 W*
7L5Z3078A	ARM LOWER CONTR RH
6L5Z3084AA	ARM, CONTROL 1 PIECE (FFV)
6L5Z3079BA	ARM, CONTROL LOWER LS (00-01 FFV)
6L5Z3085AA	ARM, CONTROL UPPER LH (00-01 FFV)
XL2Z14300BA	BATTERY CABLE ASSY FFV
XW4Z4221AA	BEARING CARRIER
B7C1201A	BEARING, INNER WHEEL (FFV)
B5A1216A	BEARING, OUTER WHEEL (FFV)
F2DZ3E700A	BEARING, STEERING COLUMN LOCK HOUSING (FFV)
F4DZ3517A	BEARING, STEERING COLUMN LOWER SMALL (FFV)
F3TZ3517A	BEARING, STEERING COLUMN UPPER (FFV)
XF2Z8620CB	BELT 2003 WINDSTAR
XS2Z8620NA	BELT, DRIVE 71.7 INCHES
XL2Z8620AA	BELT, FAN (FFV)
E9TZ10852A	BEZEL, HEADLAMP (FFV)
09801578A	BLADE, WIPER (FFV)
09801578	BLADE, WIPER 22
09801578HD	BLADE, WIPER WINTER
N805163S100	BOLT CALIPER FRT FFV
N811747S2	BOLT MANIFOLD TO EXHA FFV
E802185S72	BOLT, (FFV)
F77Z6379AC	BOLT, FLYWHEEL TO CRANKSHAFT (FFV)
F77Z2005AA	BOOSTER, (FFV)
602068	BOOT, CV AXLE COMPLETE LS (FFV)
602069	BOOT, CV AXLE COMPLETE RS (FFV)

Part Number	Description
1W7Z2V321CA	BOOT, FRONT BRAKE (FFV) DISC BRAKE HARDWARE KIT
F5TZ3A331A	BOOT, FRONT WHEEL INNER OR OUTER. (FFV)
YL2Z5A242AA	BRACKET, (FFV)
F5TZ2C402B	BRACKET, ANCHOR FRONT BRAKE CALIPER (FFV)
08611105	BRACKET, MIRROR REAR CROSSWALK (FFV)
F87Z5486BA	BRACKET, STABILIZER FRONT (FFV)
F77Z7B229HA	BRACKET, TRANS SHIFT CONTROL CABLE (FFV)
F77Z2A635DB	BRAKE CABLE RH FFV
6L5Z2078AA	BRAKE HOSE LH FRT FFV
8L5Z2078R	BRAKE HOSE RH FRT FFV
F87Z1104CA	BRAKE HUB W/SENSOR FFV
6L5Z3086AA	BUSHING KIT CONTROL ARM
F3TZ7L278A	BUSHING, SHIFT TUBE (FFV/ 98 WSTAR)
4L2Z5484DA	BUSHING, STABILIZER (FFV)
10097580	CABLE RR DOOR LATCH FFV
F87Z9A758HB	CABLE, ACCELERATOR PEDAL TO CARBURETOR THROTTLE (00 FFV)
1L2Z9A758FA	CABLE, ACCELERATOR PEDAL TO CARBURETOR THROTTLE (01 FFV)
XL2Z14300HA	CABLE, BATTERY POS/NEG (FFV)
F77Z2A635DC	CABLE, PARK BRAKE REAR (FFV) LS
10997506	CABLE, REAR DOOR ((FFV)) COUNTER BALANCE
XL2Z2A635AB	CABLE, REAR PARK BRAKE RS (FFV)
XL2Z7E395AA	CABLE, SHIFT (FFV)
N606046S60	CALIPER BOLT REAR FFV
F57Z2553AD	CALIPER LOADED REAR
F57Z2V552AD RM	CALIPER, BRAKE (00-01 FFV)
F57Z2V553AD RM	CALIPER, BRAKE (00-01 FFV)
1L2Z2V321BA	CALIPER, BRAKE REAR (FFV) KIT
F5TZ3B236A	CAM, FRONT SUSPENSION ARM (FFV)
F5TZ3C203A	CAM, FRONT SUSPENSION LOWER ARM ADJUSTMENT (FFV)
LF1131B	CAP, DUST FRONT WHEEL BEARING (FFV)
XU5Z9030JA	CAP, FUEL (FORD/ FFV/ TAURUS) TETHER CORD
XU5Z9030JAFD	CAP, FUEL (FORD/ FFV/ TAURUS) TETHER CORD
XU5Z9030MA	CAP, FUEL 1/8 TURN
F3AZ6766B	CAP, OIL FILLER (FFV/ 98 WSTAR/ 97 ASTAR)
XF2Z7A214AA	CAP, OVERDRIVE SHIFT (FFV)
E9S28100A	CAP, RADIATOR (98 WSTAR/ FFV)
QG1850	CHAINS FFV
SZ339	CHAINS, TIRE (FFV)



6400 E. Industrial Lane • Leavenworth, IN 47137
 Phone: 800-752-1700 • Fax 215-781-2618
www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – FFV

Part Number	Description
XC2Z10K843AA	CIRCUIT, INSTRUMENT CLUSTER PRINTED) (FFV)
F2DZ7E400A	CLAMP, SHIFT SHAFT (FFV)
F2UZ7C464A	CLIP, SHIFT LEVER (FFV)
6L5Z8A616BA	CLUTCH, FAN (00-01 FFV)
FOAZ8115A	COCK, RADIATOR DRAIN (98 WSTAR/ FFV)
FOTZ12029A	COIL, IGNITION 2.5 (FFV)
F1DZ7H181A	CONNECTOR SHIFT
F7TZ8594A	CONNECTOR, BEFORE 36731 (FFV)
E7TZ7D273A	CONNECTOR, FLUID TUBE TRANS MOUNTED (FFV)
F8Z714A664AB	CONTACT, HORN (FFV)
5L5Z7A095A	COOLER, TRANS (00-01 FFV)
YL5Z7A095BA	COOLER, TRANS OIL FROM 1/19/00 (FFV)
F5TZ18476A	CORE, HEATER
F7Z76582BE	COVER VALVE LEFT SIDE
QG5820	CROSS LINK
B7C1202A	CUP, BEARING INNER WHEEL (FFV)
B5A1217B	CUP, BEARING OUTER WHEEL (FFV)
C6TZ4222A	CUP, DIFFERENTIAL BEARING (FFV)
6L5Z2140A	CYLINDER, BRAKE MASTER
F8Z7A020DA	DIPSTICK
XL2Z6750DA	DIPSTICK, ENGINE (FFV)
1L5A12A650AE	ECM
F8Z73A130BA	END, STEERING LINKAGE OUTER TIE ROD (FFV)
F8Z73A130BA FD	END, STEERING LINKAGE OUTER TIE ROD (FFV)
XW4Z2A602AA	EQUALIZER, PARK BRAKE (FFV)
YL2Z5230BA	EXHAUST ASSM, MUFFLER WITH TAIL PIPE SINGLE INLET (FFV)
F8Z78600EA	FAN, BLADE (FFV)
17990759	FAN, DASH DRIVER COMFORT (FFV & MACK)
F6Z716055AC	FENDER, FRONT INNER LS (FFV)
2L5Z6A666BA	FILTER PCV 2001 FFV
F7Z9601AA	FILTER, AIR (FFV)
XL5Z9155AA	FILTER, FUEL (00 FFV)
XL5Z9155AAFD	FILTER, FUEL (00 FFV)
F89Z9155A	FILTER, FUEL (99 WSTAR/00 FFV)
F1AZ6731BD	FILTER, OIL (01 FFV)
D9AZ6731A	FILTER, OIL (FFV/DODGE/97 ASTAR)
XL2Z7A098CA	FILTER, TRANS (FFV)
XL2Z7A098CA KT	FILTER, TRANS (FFV)
F6TZ13350AA	FLASHER 25 AMP FFV
5L5Z13350AA	FLASHER, HAZARD & TURN SIGNAL (FFV)
5L5Z13350AA FD	FLASHER, HAZARD & TURN SIGNAL (FFV)

Part Number	Description
F7Z76375AA	FLYWHEEL, (FFV)
MS90890	GASKET INTAKE KIT FFV
E9TZ5E241A	GASKET, CIRCULAR CONVERTER OUTLET PIPE FLANGE (FFV)
RDS55341	GASKET, DIFF ASSY COVER FFV
E6AZ9D476B	GASKET, EXHAUST GAS RECIRCULATION VALVE (FFV)
1L5Z5B266AA	GASKET, EXHAUST INLET PIPE (FFV)
F5TZ7A191A	GASKET, FLUID PAN (FFV)
YL2Z9E436AA	GASKET, FUEL RAIL TO PLENUM (FFV)
YL2Z9E436AAFD	GASKET, FUEL RAIL TO PLENUM (FFV)
YL2Z9461AA	GASKET, INTAKE MANIFOLD LOWER (00 FFV)
1L2Z9461CA	GASKET, INTAKE MANIFOLD LOWER (01 FFV)
F7Z75C226AA	GASKET, LS CONVERTER TO DUAL INLET (FFV)
F5TZ6734BA	GASKET, OIL DRAIN PLUG (FFV)
4L2Z6710AA	GASKET, OIL PAN LOWER (00-01 FFV)
W70Z837S300	GASKET, THERMOSTAT EARLY (FFV)
1L2Z8255AA	GASKET, THERMOSTAT WATER OUTLET CONNECTION FROM 7/24/00 (FFV)
XF2Z9H486AA	GASKET, UPPER INTAKE MANIFOLD FFV
1L2Z6584AA	GASKET, VALVE COVER FROM 7/24/00 LS OR RS (FFV)
23002041	HANDLE, WINDOW CRANK SQ DRV (LLV/FFV)
818499	HEAD ASSY - LT FOR 184910 JET FFV
818491	HEAD ASSY - RT FOR 184910 JET FFV
HS9293PT	HEAD GASKET SET FFV 184910
16512669	HEADLAMP, (FFV)
XL5Z6A051AA	HEATER, BLOCK (FFV)
2L3Z13832AA	HORN & SUPPORT
2WZ7Z13800AA	HORN, HIGH NOTE00-01 FFV/97-98 ASTAR)
2WZ7Z13800BA	HORN, LOW NOTE (00-01 FFV/97-98 ASTAR)
F7Z73A713DA	HOSE POWER STRG.RETURN
F6Z722078FA	HOSE, BRAKE FRONT RS (FFV) USE 8L5Z2078R
F7Z718472AAA	HOSE, HEATER
F7Z718472CC	HOSE, HEATER
F7Z718472EA	HOSE, HEATER
YL2Z18472CA	HOSE, HEATER
YL2Z18472BA	HOSE, HEATER SUPPLY LINE (FFV)
YL2Z18472BAFD	HOSE, HEATER SUPPLY LINE (FFV)
F7Z76C342AB	HOSE, PCV (FFV)
F8Z78286HA	HOSE, RADIATOR LOWER (FFV)
4L5Z8260BA	HOSE, RADIATOR UPPER (01 FFV)
YL2Z4A058AA	HOSE, REAR AXLE VENT (FFV)
F6Z72282BA	HOSE, REAR BRAKE LS (FFV)
XL2Z2282AA	HOSE, REAR BRAKE RS (FFV)



6400 E. Industrial Lane • Leavenworth, IN 47137
 Phone: 800-752-1700 • Fax 215-781-2618
www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – FFV

Part Number	Description
F77Z3A713D	HOSE, STEERING COOLER GEAR RETURN (FFV)
F77Z3A719PA	HOSE, STEERING PUMP GEAR PRESSURE UPPER (FFV)
XL2Z3A719EA	HOSE, STEERING PUMP TO GEAR LOWER PRESSURE (FFV)
F77Z8548AF	HOSE, WATER BY-PASS (FFV) LWR THERMO HSING TO TOP OF WATER PUMP
2L5Z8592BB	HOUSING LOWER THERMO FFV
YU3Z8A586AA	HOUSING, THERMOSTAT BEFORE 36731 (FFV)
F8UZ7A110AB	INDICATOR, SHIFT (FFV & CRV)
1L2Z9F593CA	INJECTOR FUEL 2001 FFV
F5TZ8124A	INSULATOR, RADIATOR MOUNTING LOWER (FFV)
2L3Z3050AA	JOINT, LOWER BALL (FFV)
XL2Z2001HD	KIT BRAKE PAD FRONT
XL2Z2200HD	KIT BRAKE PADS REAR
F5AZ4947BA	KIT PLATE REAR AXLE
1L2Z2225BA	KIT, BRAKE CALIPER
1L2Z2V321AA	KIT, BRAKE PADS W/HARDWARE (FFV)
FMK01F	KIT, FILTERS OIL/AIR/FUEL (01 FFV)
6L1Z4947B	KIT, REAR AXLE PLATE (00-01 FFV)
1L3Z2225CA	KIT, SPRING KIT PARK BRAKE FFV
1L2Z2386AA	KIT,CALIPER
F3DZ18519A	KNOB, HEATER CONTROL (FFV)
40203	LAMP
44221Y	LAMP
16513680	LAMP STOP LED
16512666	LAMP, BACK UP (FFV)
16512709	LAMP, BRAKE (FFV)
16512726	LAMP, BRAKE CENTER (FFV)
16512726LED	LAMP, BRAKE CENTER LED (FFV)
16512707	LAMP, HAZARD AMBER LENS & REAR TURN (FFV)
16512710	LAMP, MARKER SIDE FRONT (FFV)
16512711	LAMP, MARKER SIDE REAR (FFV)
16512707LS	LAMP, STROBE ASSM KIT (FFV)
10997580	LATCH CABLE FFV
3L2Z2A638AA	LEVER E-BRAKE L/S FFV
7L5Z7210AA	LEVER SHIFT
F5TZ2C637A	LEVER, BRAKE CONTROL (FFV)
XL2Z2780BB	LEVER, PARK BRAKE (FFV)
F5TZ2A638A	LEVER, PARK BRAKE LS (FFV)
F2DZ7D282A	LEVER, TRANS SHIFT SELECTOR (FFV)
F77Z5K483KIT	LINK, FRONT SWAY BAR (FFV)
2L2Z5K483BA	LINK, STABLIZER FFV
XF2Z2140BB	MASTER CYLINDER 03 WSTAR
08610754	MIRROR, CONVEX REAR (FFV)
08610790	MIRROR, SIDE SS LS (FFV)
08610791	MIRROR, SIDE SS RS (FFV)
97251	MODULE, LIGHT STROBE

Part Number	Description
6L5Z17508AA	MOTOR WIPER
17990749	MOTOR, HEATER BLOWER WO/CAGE (FFV)
F5TZ6068A	MOUNT, TRANSMISSION (FFV/ 97 ASTAR)
F87Z17603AA	NOZZLE, W/S WASHER (FFV)
N801673S436	NUT REAR STB.MTG.BRKT.FFV
N801995S2	NUT&WSHR RR STB.BRKT FFV
379299S2	NUT, 3/8
W702586S301	NUT, EXH. MANIFOLD M8 HEX FLANGE HIGH TEMP (FFV)
W705443S900	NUT, EXHAUST (FORD)
390622S	NUT, FRONT HUB RETAINER 49/64
374504S100	NUT, SPINDLE 3/4
D3TZ2457B	PAD, BRAKE PEDAL (FORD/ 97 ASTAR/ FFV)
XL2Z2200AA	PADS, BRAKE (FFV)
XL2Z2001BA	PADS, BRAKE FRONT (FFV)
5R3Z6675AA	PAN, OIL LOWER (00-01 FFV)
XL5Z15A851AA	PARK BRAKE SWITCH FFV
FODZ7G357A	PIN, SHIFT TUBE (FFV)
FODZ7W441A	PIN, SHIFT TUBE (FFV)
F6TZ6730BA	PLUG, OIL DRAIN (FFV)
AGSF32FMF4	PLUG, SPARK (98 WSTAR/FFV)
F57Z3F785AAB	PLUG, STEERING WHEEL REAR BLACK (FFV)
F7DZ7R264AA	PLUNGER, SHIFT LEVER (FFV)
1L2Z9H307GH	PUMP, FUEL (FFV) USE 1L2Z9H307A
F77Z3A674EBRM	PUMP, POWER STEERING (FFV)
F75Z17664BB	PUMP, W/S WASHER (FFV)
6L2Z8501A	PUMP, WATER (00-01 FFV)
1L5Z8005NA	RADIATOR FFV 2001
XL2Z8005DA	RADIATOR, (FFV)
88838901	REGULATOR WINDOW LONG VER
F5TZ14N089B	RELAY, HORN (FFV)
YL2Z17618AA	RESERVOIR, W/S WASHER (FFV)
4L5Z19A706AA	RESISTOR ASY. FFV
F5AZ2A492AA	RETAINER, BRAKE
13672444	RISER SEAT SKIRT
13672443	RISER, DRIVER SEAT (FFV)
F57Z3280AA	ROD, FRONT WHEEL SPINDLE CONNECTING (FFV)
XL5Z1125CA	ROTOR, BRAKE 4WD (FFV)
4L5Z1102BA	ROTOR, BRAKE FRONT (00-01 FFV)
4L5Z1102BAFD	ROTOR, BRAKE FRONT (00-01 FFV)
YL2Z1V125AA	ROTOR, BRAKE FRONT 4WD
W710669S439	SCREW, HEAT SHIELD WITH WASHER (00-01 FFV)
FOPZ9229A	SEAL KIT O-RING LOWER FFV
E6TZ6700A	SEAL, CYLINDER FRONT COVER OIL (FFV)
F89Z4676AA	SEAL, DRIVE PINION OIL (FFV)
5L8Z4B416AA	SEAL, FRONT AXLE SHAFT OIL (FORD)



6400 E. Industrial Lane • Leavenworth, IN 47137

Phone: 800-752-1700 • Fax 215-781-2618

www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – FFV

Part Number	Description
F57Z3254AA	SEAL, FRONT AXLE SHAFT OIL RS (FFV)
F57Z3332AA	SEAL, FRONT SUSPENSION STEERING BALL STUD (FFV)
388897S	SEAL, POWER STEERING .455ID (00-01 FFV/97-98 ASTAR & WSTAR)
388898S	SEAL, POWER STEERING .515ID (00-01 FFV/97-98 ASTAR & WSTAR)
E3TZ1S177A	SEAL, REAR HUB AND DRUM OIL (FFV)
F67Z1S177ACA	SEAL, REAR WHEEL (FFV)
10997504	SEAL, ROLL-UP DOOR HEADER 53
4L5Z7052AA	SEAL, TRANS EXT HOUSING OIL (00-01 FFV/97 ASTAR)
FOZZ1S190A	SEAL, WHEEL FRONT (FFV & ASTAR)
13672441	SEAT, (FFV)
XL2Z9A299AB	SENDER, FUEL TANK
F7DZ10884AA	SENDER, WATER TEMPERATURE (98 WSTAR/ FFV)
F7RZ7H103BA	SENSOR OUTPUT SPEED SHAFT FFV
F4SZ9B989AA	SENSOR THROTTLE POSITION 2003 WINDSTAR
F85Z2L373AC	SENSOR, ABS (FFV)
6L5Z2C204AA	SENSOR, ABS RS
6L5Z2C204BA	SENSOR, BRAKE FRONT (00-01 FFV)
F77Z12A648AA	SENSOR, COOLANT TEMPERATURE 2 FLAT PINS (00 FFV)
F77Z9J460AB	SENSOR, EGR (FFV/ WSTAR)
XS4Z9C052AA	SENSOR, FUEL PRESSURE TANK (FFV)
XF2Z12B579A BRM	SENSOR, MASS AIRFLOW (FFV)
F85Z9G444AB	SENSOR, OXYGEN #2 BANK IN CONV (FFV/ WSTAR)
E9LZ9E731A	SENSOR, SPEED (98 WSTAR/ FFV)
XL3Z9F472BA	SENSOR, UPSTREAM EXH GAS OXY (FFV)
F87Z5776AA	SHACKLE SPRING REAR
F87Z3B676EB	SHAFT, STEERING COLUMN LOWER (FFV)
F87Z2K005DA	SHIELD, FRONT DISC BRAKES ROTOR 4X2 LS (FFV)
F87Z2K004DA	SHIELD, FRONT DISC BRAKES ROTOR 4X2 RS (FFV)
4U2Z18V124AA	SHOCK, (FFV)
3U2Z18124CF	SHOCK, FRONT
3U2Z18125CA	SHOCK, REAR (FFV)
13112552	SHOCK, SEAT FREIDMAN (FFV)
XL2Z2648AA	SHOES, BRAKE EMERGENCY KIT (FFV & CRV)
F87Z8146HA	SHROUD, FAN (FFV)
F5TZ2A648A	SLIPPER, BRAKE CALIPER ANCHOR (FFV)
7818	SOCKET & PIGTAIL H/LITE
F63Z9J459AA	SOLENOID, EGR (98 WSTAR/ FFV)
XL2Z7G383AA	SOLENOID, PRESSURE CONTROL (FFV)
F77Z7G484AB	SOLENOID, SHIFT CONTROL (FFV)

Part Number	Description
F2DZ3Z719A	SOLENOID, SHIFT INTERLOCK (FFV)
XL2Z16102AA	SPLASHGAURD FRONT RH
XL2Z16103AA	SPLASHGAURD FRT.LH
F58Z2068A	SPRING, BRAKE HOLD DOWN (FFV)
F5TZ7E332A	SPRING, DETENT (FFV)
F3TZ4214A	SPRING, DIFFERENTIAL CLUTCH REAR AXLE (FFV)
6L5Z7379A	SPRING, SHIFT (00-01 FFV/97 ASTAR & 98 WSTAR)
F89Z11002BA	STARTER, (FFV)
F89Z11002BARM	STARTER, (FFV/ 97 ASTAR)
N805994S36	STUD M10X1.5X1 STR FFV
W705495S900	STUD MANIFOLD
6L5Z5495AA	STUD SWAY BAR LINK FFV
W705444S900	STUD, EXHAUST MANIFOLD (00-01 FFV)
F0VY1107A	STUD, REAR WHEEL (FFV)
3L2Z16138AA	SUPPORT, RADIATOR (00-01 FFV)
E9TZ13480A	SWITCH, BRAKE LIGHT (FFV/ 98 WSTAR)
16512959	SWITCH, CARGO LIGHT REAR (FFV)
16511993	SWITCH, FAN & HAZARD FLASHER (2 TON/ FFV)
6C2Z11654A	SWITCH, HEADLIGHT (FFV & ASTAR)
E7TZ11654B	SWITCH, HEADLIGHT (FFV & ASTAR)
F4DZ11572B	SWITCH, IGNITION (FFV/ 98 WSTAR)
F7LZ7F293AB	SWITCH, NEUTRAL SAFETY (FFV)
6U5Z9278D	SWITCH, OIL PRESSURE (00-01 FFV)
F37Z15A851A	SWITCH, PARK BRAKE LEVER (FFV)
3F1Z13480AA	SWITCH, STOP LIGHT (00 FFV)
XF5Z13K359BA	SWITCH, TURN SIGNAL (FFV)
16512173	SWITCH, VENT FAN (FFV & 2 TON)
F87Z9002NA	TANK, FUEL (FFV)
6L2Z6B209A	TENSIONER, BELT (00-01 FFV)
F77Z6B209AA	TENSIONER, BELT (97 ASTAR/ FFV)
YL2Z9E473AA	TENSIONER, INTAKE UPPER AND LOWER (FFV)
XU3Z6K254BA	TENSIONER, TIMING CHAIN (00-01 FFV)
1L2Z8575AA	THERMOSTAT, (FFV)
YU3Z8575AA	THERMOSTAT, FFV
F87Z7G550AA	TRANS SWITCH OD
F77Z10732AA	TRAY, BATTERY (FFV)
4L5Z6758HA	TUBE, CRANKCASE VENT (01 FFV)
YL2Z9A274AA	TUBE, FUEL FILTER SUPPLY (FFV)
XL2Z9J280AA	TUBE, FUEL FROM TANK TO FUEL FILTER (FFV)



6400 E. Industrial Lane • Leavenworth, IN 47137
 Phone: 800-752-1700 • Fax 215-781-2618
www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – FFV

Part Number	Description
F57Z7212A	TUBE, SHIFT (FFV)
E4TZ5705B	UBOLT LEAF SPRING FFV
F2AZ4635C	U-JOINT, (FFV)
8L5Z3085L	UPPER LS ARM (OLD 3L5Z3083AA)
4L5Z8592AA	UPPER THERMO HOUSING
4U7Z6582A	VALVE COVER FFV
F77Z9D475F2A	VALVE EGR 2000 FFV
YF1Z6A666AA	VALVE PCS FFV
F87Z9D475A2A	VALVE, EGR (98 WSTAR)

Part Number	Description
XC2Z9D475AB	VALVE, EXHAUST GAS RECIRCULATION) IDENTIFICATION # XC2E9D475A3A (FFV)
F67Z9B593CA	VALVE, FUEL VAPOR IN-TANK MOUNTED (FFV)
5L5Z9F715A	VALVE, IDLE AIR (00-01 FFV)
2L5Z9F715BA	VALVE, IDLE AIR CONTROL (FFV)
YU3Z9F715AA	VALVE, IDLE AIR CONTROL (FFV)
FOZZ6A666A	VALVE, PCV (FFV)
XU2Z6M252AA	WASHER T/CHAIN LH
E7TZ1195A	WASHER, OUTER BEARING RETAINER (FFV)
XU2Z12259FA	WIRES, SPARK PLUG SET (FFV)