



6400 E. Industrial Lane • Leavenworth, IN 47137
 Phone: 800-752-1700 • Fax 215-781-2618
www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – 98 & 03 WINDSTAR

Part Number	Description
6L3Z25218A4 3AA	ACTUATOR DRIVER DOOR W*
XF2Z10V346B ARM	ALTERNATOR 03W*
XF2Z10346BA	ALTERNATOR ASY. 2003 W*
F6PZ10346LA RM1	ALTERNATOR, (97 ASTAR)
F78Z3079CA	ARM, CONTROL LOWER LS (98 WSTAR)
F78Z3078CA	ARM, CONTROL LOWER RS (98 WSTAR)
XF2Z17526AC	ARM, W/S WIPER LS (98 WSTAR)
F58Z17526C	ARM, W/S WIPER REAR (98 WSTAR)
F68Z3V427AA RM	AXLE, CV LS (98 WSTAR)
F88Z5482AA	BAR, STABILIZER FRONT (98 WSTAR)
E9SZ13776C	BASE, DOME LIGHT (98 WSTAR)
EOZZ7F431B	BEARING, REAR WHEEL (WSTAR)
E9DZ1215A	BEARING, WHEEL FRONT OUTER (98 WSTAR)
F88Z16611B0 8AAC	BELT SEAT 98W*
F78Z8620CA	BELT, SERPENTINE (98 WSTAR)
F58Z8620A	BELT, SERPENTINE (WSTAR)
F58Z17528E	BLADE, WIPER 31-20 RS (98 WSTAR)
F58Z17528AC	BLADE, WIPER REAR 16
F58Z2005A	BOOSTER BRAKE 1998W*
2F2Z2A713AA	BOOT, HAND BRAKE (WSTAR)
F68Z3A331AA	BOOT, INNER LS (98 WSTAR)
XL3Z3D677AAB	BOOT, SHIFT LEVER (WSTAR)
1L3Z2V386AA	BRAKE CALIPER KIT
XG3A	BRAKE CALP. LUBE
98WSSBLKTF	BRAKE LINE KIT 98 W* FRNT
98WSSBLKT	BRAKE LINE KIT 98 WINSTR
F78Z1661203 ABG	BUCKLE, SEAT BELT LS (98 WSTAR)
F5RZ9F955AB	BUSHING 2003W*
F58Z3C067A	BUSHING FRONT 2PER BOX W*
F58Z5493A	BUSHING STAB BAR 2PER BOX
F58Z9A758D	CABLE ACCELERATOR W*
F68Z14301BC	CABLE, BATTERY NEGATIVE (98 WSTAR)
F68Z14300BD	CABLE, BATTERY POSITIVE (98 WSTAR)
F78Z2853AA	CABLE, BRAKE FRONT (98 WSTAR)
F58Z2A635B	CABLE, BRAKE LS REAR (98 WSTAR)
F58Z2A635A	CABLE, BRAKE RS REAR (98 WSTAR)
XF2Z7E395AA	CABLE, SHIFT (98 WSTAR)
F6DZ8100A	CAP COOLANT TANK
F2UZ7A214CA	CAP, SHIFT OVERDRIVE (98 WSTAR/97 ASTAR)
XF2Z16222A0 0AA	CHANNEL, DOOR FRONT RS WINDOW (WSTAR)
F58Z1622412A	CLIP HANDLE
F68Z1622023AA	CLIP, DOOR LOCK (98 WSTAR)

Part Number	Description
F77Z3D746CA	COIL COOLING
F5SZ12029A	COIL, IGNITION (98 WSTAR)
F58Z12A112AA	COIL, IGNITION PICK UP (98 WSTAR)
F58Z7D273A	CONNECTORS TRAN COOLER
XF2Z14A658AA	CONTACT SLIDING DOOR WIN
F58Z14A658D	CONTACT, PWR DOOR LOCK PILLAR SLIDING DOOR (98 WSTAR)
7F2Z2C215BA RM	CONTROL BRAKE W*
XF2Z9J559AA	CONTROL INTAKE MANI RUN
F78Z5F250AA	CONVERTER & PIPE 1998 W*
F58Z8A080A	COOLANT RECOVERY TNK 98W*
F78Z1664416A AC	COVER SEAT BACK W*
F78Z17D957H HCP	COVER, FRONT BUMPER (98 WSTAR)
F88Z1664416A AC	COVER, SEAT BACK (WSTAR)
F88Z1662901A AC	COVER, SEAT LOWER CUSHION (WSTAR)
F88Z2140BA	CYLINDER, BRAKE MASTER (WSTAR)
1F1Z2V261BA	CYLINDER, WHEEL (98 WSTAR)
XF2Z14A658BA	DOOR SIDE TERMINAL W* 03
XF2Z14A658DA	DOOR SIDE TERMINAL W* 03
XF2Z14A658CA	DOOR SLIDE CONTACT W* 03 POWER
1F2Z14529AAA	DOOR SWITCH
F58Z1126A	DRUM, BRAKE REAR (98 WSTAR)
F8PZ12A650B HA	ECM, (WSTAR)
1F2Z3280AA	END, TIE ROD OUTER (WSTAR)
3F2Z3A130BA	END, TIE ROD OUTER RS & LS (98 WSTAR)
F6DZ9601B	FILTER, AIR
E6AZ9601B	FILTER, AIR (98 WSTAR/ 97 ASTAR)
XF2Z9601AC	FILTER, AIR (99 WSTAR)
XF2Z19N619AB	FILTER, CABIN (03 WSTAR)
E4FZ6731AB	FILTER, OIL (98 WSTAR)
F5TZ7A098B	FILTER, TRANS (97 ASTAR)
F6DZ7A098AA	FILTER, TRANS KIT (98 WSTAR)
F58Z16A550B	FLAP, MUD, REAR LS (98 WSTAR)
F58Z16A550A	FLAP, MUD, REAR RS (98 WSTAR)
5C3Z13350AA	FLASHER, TURN SIGNAL (98 WSTAR)
DOT3	FLUID, BRAKE DOT 3
DOT3B	FLUID, BRAKE DOT 3 12 OZ
F68Z6375BA	FLYWHEEL, (98 WSTAR)
F5DZ6375A	FLYWHEEL, ENGINE (98 WSTAR)
1L2Z9F775AA	FUEL DAMPER ASM
F78Z9417AA	GASKET, FUEL PUMP
YF1Z8255CA	GASKET, THERMOSTAT WATER OUTLET RG609 (WSTAR)



6400 E. Industrial Lane • Leavenworth, IN 47137
 Phone: 800-752-1700 • Fax 215-781-2618
www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – 98 & 03 WINDSTAR

Part Number	Description
F87Z8255DA	GASKET, THERMOSTAT WATER OUTLET RG621 (98 WSTAR)
F6DZ7A191A	GASKET, TRANS (98 WSTAR/LLV)
F78Z9280AA	GAUGE FUEL 98W*
F58Z17K707E	GLASS, MIRROR LS (98 WSTAR)
F58Z17K707E FD	GLASS, MIRROR LS (98 WSTAR)
F58Z17K707C	GLASS, MIRROR RS (98 WSTAR)
F88Z17B968AA	GRILLE
TJG837581	HANDLE WINDOR CRANK
F58Z1643400A	HANDLE, BACK LATCH (98 WSTAR)
F7DZ5431406 AAC	HANDLE, DOOR (WSTAR)
F78Z1626600 BA	HANDLE, DOOR OUTSIDE SLIDING (WSTAR)
F37Z1023342A	HANDLE, WINDOW (98 WSTAR)
F78Z13008AB	HEADLAMP, (98 WSTAR)
F78Z13008BA	HEADLAMP, (98 WSTAR)
6L5Z1022800 AA	HINGE FRT.DOOR WINDSTAR
F78Z1622810 AA	HINGE, DOOR FRONT LOWER LS OR RS (98 WSTAR)
F88Z1622800 AA	HINGE, DOOR LS FRONT UPPER (98 WSTAR)
F58Z1642900A	HINGE, REAR LIFT GATE (98 WSTAR)
XF2Z1604810 BAA	HOLDER, CUP (WSTAR)
F78Z16612AE	HOOD, (WSTAR)
XF2Z3A719BA	HOSE P/S PRESSURE
F58Z2078A	HOSE, BRAKE FRONT (RS) (98 WSTAR)
3F2Z2282CA	HOSE, BRAKE REAR LS (WSTAR)
3F2Z2282CB	HOSE, BRAKE REAR RS (WSTAR)
F78Z3A713LA	HOSE, POWER STEERING RETURN COOLER TO PUMP (98 WSTAR)
F58Z8286B	HOSE, RADIATOR LOWER (98 WSTAR) 3.8 L ITER
F58Z8260A	HOSE, RADIATOR UPPER (98 WSTAR)
F58Z8260AFD	HOSE, RADIATOR UPPER (98 WSTAR)
F78Z3A719JA	HOSE, STEERING PUMP TO GEAR PRESSURE (98 WSTAR)
F88Z3A713DA	HOSE, STEERING RETURN (98 WSTAR)
F78Z3A713JA	HOSE, STEERING RETURN LINE COOLER W/O FINS MTS FT RADIATOR (98 WSTAR)
1F2Z1104AA	HUB & BEARING FRT. 2003W*
F68Z1104AA	HUB, FRONT (WSTAR)
1L3Z11582A	IGN CYLINDER W* & AREO*
F58Z2C182B	INDICATOR, ANTI-LOCK (98 WSTAR)
F78Z7A110AB	INDICATOR, SHIFT PRNDL (98 WSTAR)
F58Z3C078A	INSULATOR FRONT W*
F78Z17C882AA	INSULATOR,
F68Z5F262AA	INSULATOR, EXHAUST HANGER (98 WSTAR)
F87Z5493CA	INSULATOR, FRONT STABILIZER BAR
YF2Z9439AA	INTAKE GASKET 98 WINDSTAR

Part Number	Description
YF2Z9439BA	INTAKE GASKET 98 WINDSTAR
XF2Z9J559A	INTAKE RUNNER CON 2003WIN
3F2Z9S479AA	ISOLATOR BOLT 03 WINDSTAR
1L2Z2225AA	KIT, BRAKE HARDWARE
1F2Z2225AA	KIT, HARDWARE REAR (98 WSTAR)
YF2Z16404D0 2AA	KIT, REAR LIFT GATE REPAIR (98 WSTAR)
F78Z15A201AB	LAMP, MARKER SIDE LS FRONT (98 WSTAR)
F78Z15A201AA	LAMP, MARKER SIDE RS FRONT (98 WSTAR)
3F2Z13404CA	LAMP, TAIL (03 WSTAR)
3F2Z13405CA	LAMP, TAIL (03 WSTAR)
F58Z13405A	LAMP, TAIL LIGHT ASSM LS (98 WSTAR)
F58Z13404A	LAMP, TAIL LIGHT ASSM RS (98 WSTAR)
XF2Z1643170 BA	LATCH, DOOR REAR INSIDE ASSY (WSTAR)
E9SZ13783A	LENS, DOME LIGHT (98 WSTAR)
F78Z2780AA	LEVER, PARK BRAKE (98 WSTAR)
F88Z7210AA	LEVER, SHIFT (98 WSTAR)
2F2Z17683BA	LH SIDE MIRROR, POWER CONTROL 03 WINDSTAR NON-HEATED
XF2Z16406A1 1AA	LIFT ASY 2003 W* LH
XF2Z16406A1 0AA	LIFT ASY. 2003 W* RH
6R3Z5K483A	LINK STABILIZER WINDSTAR
2F2Z16431A38 AA	LOCK ACTUATOR REAR HATCH 2003 WINDSTAR
F78Z1622050AA	LOCKSET, (98 WSTAR)
6U5Z17700A	MIRROR INSIDE W*
3F2Z17683GA	MIRROR LS 2003 W* (POWER)
3F2Z17682GA	MIRROR RH 03 W* (POWER)
714147	MIRROR, CONVEX REAR (98 WSTAR)
F5SZ17700AA	MIRROR, REAR (WSTAR)
F78Z17683EAA	MIRROR, SIDE LS (98 WSTAR)
F78Z17682EAA	MIRROR, SIDE RS (98 WSTAR)
F78Z14B205AA	MODULE, (98 WSTAR)
6F2Z7823394BA	MOTOR WIND REG RH 2003 W
6F2Z7823395BA	MOTOR WINDOW LH 2003 WIND
F68Z19805FC	MOTOR, HEATER BLOWER (98 WSTAR)
XF2Z19E616FB	MOTOR, HEATER DOOR (03 WSTAR)
F78Z17508AB	MOTOR, WIPER REAR (98 WSTAR)
XF2Z6038BA	MOUNT, MOTOR FRONT RS (98 WSTAR)
XF2Z6068BA	MOUNT, MOTOR REAR L/S (98 WSTAR)
F58Z6F063AA	MOUNT, MOTOR RS FRT (98 WSTAR)
F19Z17603A	NOZZLE, W/S WASHER (WSTAR)
F58Z17603A	NOZZLE, W/S WASHER JET (98 WSTAR)



6400 E. Industrial Lane • Leavenworth, IN 47137
 Phone: 800-752-1700 • Fax 215-781-2618
www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – 98 & 03 WINDSTAR

Part Number	Description
F58Z17603B	NOZZLE, W/S WASHER REAR WINDOW (98 WSTAR)
E83Z1012A	NUT, WHEEL LUG (WSTAR)
6U5Z9278K	OIL PRESSURE SWITCH 2003 WINDSTAR
F88Z16632A2 3AA	PAD, FRONT SEAT (WSTAR)
XF2Z2001SA	PADS, BRAKE (99 WSTAR)
F88Z2001SA	PADS, BRAKE FRONT (98 WSTAR)
F58Z2001AA	PADS, BRAKE FRONT (WSTAR)
XF2Z6675EA	PAN, OIL (98 WSTAR)
F75Z6730BA	PLUG, OIL DRAIN (98 WSTAR)
E9DZ6730A	PLUG, OIL DRAIN (WSTAR)
AGSF22PP	PLUG, SPARK (WSTAR)
F4DZ6C348C	PULLEY, IDLER (WSTAR)
2F2Z9H307AC	PUMP & SENDER FUEL 2003W*
1F2Z3A674BA RM	PUMP POWER STEERING 03 W*
6U7Z8501A	PUMP WATER 03 W *
F78Z9H307BA	PUMP, FUEL (WSTAR) 1998
6F1Z17664A	PUMP, W/S WASHER (98 WSTAR)
F6SZ17664BA	PUMP, W/S WASHER (98 WSTAR)
1F1Z8501AA	PUMP, WATER (98)
3F2Z6068BA	REAR MOTOR TRANS MOUNT 03 WINDSTAR
6F2Z1723201CA	REGULATOR LH 2003W*
6F2Z1723200AA	REGULATOR RH 2003W*
XF2Z1623200 BB	REGULATOR, WINDOW DOOR FRONT RS
XF2Z1623201 BB	REGULATOR, WINDOW LS (98 W/STAR)
F88Z1623201AA	REGULATOR, WINDOW LS (98 WSTAR)
F78Z8A284AA	REINFORCEMENT, RADIATOR GRILLE
F58Z17618B	RESERVOIR, WATER W/MOTOR
4C2Z19A706BA	RESISTER ASY. A/C W*&A*
F87Z11691AA	RESISTOR LITE SW
XF2Z16222A01 AA	RETAINER, DOOR GLASS SIDE FT LS RUN (98 WSTAR)
F88Z1621547AA	RETAINER, WINDOW SIDE DOOR FT LS (98 & 99 WSTAR)
F68Z14A664CA	RING, STEERING AIR BAG (WSTAR)
N804583S	RIVET 4.0X23 WINDSTAR
YF2Z1V125BA	ROTOR, BRAKE FRONT (03 WSTAR)
F58Z1125BB	ROTOR, BRAKE FRONT (98 WSTAR)
F3DZ5E241A	SEAL, EXHAUST (98 WSTAR)
7807	SEAT HARDWARE W*
F85Z9E731AB	SENSOR
1L2Z12B579B ARM	SENSOR AIR FLOW 03 W*
XF2Z2C216BD	SENSOR REAR BRAKE 2003 W*
F1DZ7M101A	SENSOR SPEED W* 98

Part Number	Description
F58Z2C204BA	SENSOR, ABS FRONT BRAKE LS (98 WSTAR)
F58Z2C204AA	SENSOR, ABS FRONT BRAKE RS (98 WSTAR)
F78Z2C190BB	SENSOR, ABS REAR RH (98 WSTAR)
F78Z2C216BB	SENSOR, BRAKE (98 WSTAR)
1F1Z6B288BA	SENSOR, CAM 2 PRONG (98-2003 WINDSTAR)
1F1Z6C315DB	SENSOR, CRANK POSITION (98 WSTAR)
4U7Z9J460AA	SENSOR, EGR PRESSURE (WSTAR)
F72Z12B579A BRM	SENSOR, ENGINE ELECTRICAL MASS AIR FLOW (99 WSTAR)
F5DZ7F293BA	SENSOR, NEUTRAL SAFETY TRANS (98 WSTAR)
F88Z9F472AB	SENSOR, OXYGEN #1 BANK AT CONV (98 WSTAR)
F68Z3V428AA RM	SHAFT, AXLE RS (WSTAR)
1F2Z1662186A AF	SHIELD, SEAT (98 WSTAR)
1F2Z1662187A AC	SHIELD, SEAT (98 WSTAR)
F78Z16102AE	SHIELD, WHEEL LS FRONT INNER (WSTAR)
2U2Z18124BA	SHOCK, FRONT (98 WSTAR)
2F2Z18125AB	SHOCK, REAR (WSTAR)
F58Z2200EA	SHOES, BRAKE REAR (98 WSTAR)
F7TZ19554AA	SILICONE ALL GRAY TRV SIL
F78Z9F945CA	SOLENOID, VAPOR CANISTER VENT (98 WSTAR)
F59Z10718AA	SPACER, BATTERY (98 WSTAR/ 97 ASTAR)
AGSF42FM	SPARK PLUG 2003 WINDSTAR
F58Z53108	SPRING, FRONT COIL CODE RF 98 W*
F68Z11002AA RM	STARTER, (98 WSTAR)
F68Z11002BA	STARTER, (98 WSTAR)
F5TZ78434A14C	STRAP, REAR DOOR HANDLE (98 WSTAR)
F58Z16406A10A	STRUT, REAR LIFT GATE (WSTAR)
F58Z1107AA	STUD, FRONT WHEEL (98 WSTAR)
F58Z1107A	STUD, REAR WHEEL (WSTAR)
XF2Z14018AB	SWITCH ASY 2003 W*
XF2Z14018BA	SWITCH ASY 2003 W*
F4DZ19986A	SWITCH, BLOWER (98 WSTAR)
3F2Z13480CB	SWITCH, BRAKE LIGHT (WSTAR)
F58Z11691B	SWITCH, DIMMER (WSTAR)
XF1Z14018AA	SWITCH, DOOR LIFT GATE (98 WSTAR)
XF1Z10B987AA	SWITCH, DOOR RS (WSTAR)
XF1Z14018BA	SWITCH, DOOR LS FRONT BLUE (WSTAR)
F58Z11654B	SWITCH, HEADLIGHT (98 WSTAR)
XF2Z14018AD	SWITCH, INTERIOR LAMP LS DOOR (03 WSTAR)
F58Z14018B	SWITCH, SLIDING DOOR 98 WSTAR)
F58Z7G550AA	SWITCH, TRANS O/D (98 WSTAR/ 97 ASTAR)
F88Z13K359AB	SWITCH, TURN SIGNAL (98 WSTAR)



6400 E. Industrial Lane • Leavenworth, IN 47137
 Phone: 800-752-1700 • Fax 215-781-2618
www.jasperis.com • sales@jasperis.com

Jasper Innovative Solutions Parts Availability – 98 & 03 WINDSTAR

Part Number	Description
F58Z17A553B	SWITCH, W/S WIPER REAR (98 WSTAR)
F6TZ12A362CB	SYNCHRONIZER 98 W*
XF2Z12A362AA	SYNCHRONIZER 2003W*
F58Z12A362BA	SYNCHRONIZER, CAM SHAFT (98 WSTAR)
1F2Z13K359A AA	T/S SWITCH 03 W*
XF2Z8A080AA	TANK RECOVERY COOL 2003W*
XF2Z6B209AA	TENSIONER 2003 WINDSTAR
F58Z14A658CB	TERMINAL, ANTI-THEFT REMOTE CONTACT (98 WSTAR)
F8DZ8575AA	THERMOSTAT, (98 WSTAR)
F5RZ9B989BA	THRTL PSTN SENSOR 2003
TCS45771	TIMING COVER SET W*
F78Z9D477CB	TUBE, EGR (98 WSTAR)

Part Number	Description
1F1Z7212AA	TUBE, SHIFT COLUMN (WSTAR)
XF2Z9E498DD	VACUUM LINE CONNECTOR
XL2Z18495BA	VALVE HEATER
F67Z9C915CA	VALVE, EGR (WSTAR)
F78Z9C915CA	VALVE, FUEL VAPOR (98 WSTAR)
F67Z9F715AB	VALVE, IDLE AIR (98 WSTAR)
F6DZ6A666EA	VALVE, PCV (98 WSTAR)
F78Z1604105B AC	VISOR LH POWERED FOR LITE
F6DZ1007D	WHEEL, (98 WSTAR)
1U2Z12259MA	WIRE SET 03 WINDSTAR
F5PZ12259B	WIRES, SPARK PLUG SET (98 WSTAR)
XF2Z12A690AA	WIRING, ION COIL